

IMPACT OF OXY-COMBUSTION CONDITIONS ON ALKALI RELEASE AND DEPOSIT FORMATION IN RECOVERY BOILERS


Sara Hagman, Emil Vainio, Markus Engblom, Patrik Yrjas

Åbo Akademi University


2025 International Chemical Recovery Conference, September 25, 2025



Traditional Air-combustion



Oxy-combustion



Objective

- Impact of oxy-combustion on black liquor droplet burning and implications
 - Burning rate
 - Fume and emission formation
 - Elemental release
 - Impact on deposit formation

Materials & Methods


- Three different liquors (~80 %DS)
 - Spain, hardwood (BL623)
 - Nordic, softwood (BL624)
 - USA, softwood (BL626)
- Video recorded combustion experiments in the single particle reactor (SPR) with gas analyzers
 - Droplets á 10-11 mg
 - Reactor temperature 800, 900, 1000 °C
 - Two different gas compositions
 - Air/N₂ and O₂/CO₂



Gases	O ₂	N ₂	CO ₂
"Air"	3 vol-%	97 vol-%	
"Oxy"	3 vol-%		97 vol-%

Materials & Methods

- “Interrupted” tests for residue analysis (ion chromatography)
 - Droplets removed at the point of smelt formation
 - Residues dissolved in ultrapure water and analyzed by ion chromatography for Na^+ , K^+ , SO_4^{2-} and Cl^-




Results

Droplet burning at 900 °C

Air

3 % O₂ / 97 % N₂



Oxy

3 % O₂ / 97 % CO₂




"Oxy-combustion": shorter burning time due to CO₂ gasification

Spain (BL 623)



Nordic (BL 624)

USA (BL 626)

Air



Oxy





Droplet burning at different temperatures

800 °C, 3 % O₂



900 °C, 3 % O₂

1000 °C, 3 % O₂

Air





Oxy



900 °C, 3 % O₂

900 °C, 10 % O₂


Air




Oxy





Burning times




Burning times



Burning times



Burning times



Alkali release and fume formation

Alkali release and fume formation

Air



Alkali release and fume formation

Air



Oxy



"Oxy-combustion": no visible fume formation

Fume and Temperature

Spain (BL 623)

800 °C, 3 % O₂



900 °C, 3 % O₂

1000 °C, 3 % O₂

Air



Oxy




Sodium and potassium release at 1000°C

	% of BL-Na released	% of BL-K released
Air	15-30%	30-40%
Oxy	1-3%	13-15%


CO₂ inhibiting Na release

- Lower temperature of the particle in oxy-combustion conditions due to gasification reactions?
- CO₂ suppressing Na release
 - CO₂ in the gas inhibiting reduction of Na₂CO₃(l)




SO₂ formation at 900 °C

Air



Oxy




SO₂ formation during droplet burning (900 °C)

% of BL-S	Spain (BL623)	Nordic (BL624)	USA (BL626)
Air	6 %	8 %	5 %
Oxy	23 %	22 %	20 %

SO₂ formation during droplet burning (900 °C)

% of BL-S as SO ₂	Spain (BL623)	Nordic (BL624)	USA (BL626)
Air	6 %	8 %	5 %
Oxy	23 %	22 %	20 %

Note, SO₂ captured by fume in air conditions. Similar sulfur release expected, as can be seen from S retained in smelt.




Fume formation in oxy-combustion


- Sulfur release about the same as in air-fired conditions
- Alkali release significantly lower, especially sodium

Na distribution in fume

Air-firing




Oxy-firing




K distribution in fume

Air-firing




Oxy-firing






- In air-conditions virtually all sulfur in the form of sulfate in the fume
- In oxy-conditions excess SO_2 in the flue gas
- SO_3 formation (max 2% of SO_2) (10-15 ppm_v SO_3)
- <500 °C SO_3 start to form $\text{H}_2\text{SO}_4(\text{g})$

→ Possible formation of acidic sulfates (pyrosulfate and bisulfate)



Formation of acidic sulfates



Summary

- Based on these laboratory results, oxy-combustion leads to:
 - Shorter burning times (possible changes in black liquor spraying)
 - Significantly less dust formation
 - Mainly sulfate-rich fume
 - Formation of acidic sulfates, attention in economizer area
 - Scrubbing of excess SO_2 needed



Acknowledgements

- The EU CETpartnership programme
- Project partners:
 - Åbo Akademi University (coordinator), Finland
 - KTH Royal Institute of Technology, Sweden
 - University of Zaragoza, Spain
 - Andritz Oy, Finland
 - International Paper Inc., USA
 - Valmet Technologies Oy, Finland
 - Valmet Ab, Sweden



Universidad
Zaragoza

